

Proximity Sensors Inductive High Temperature Types IA, DC, M5, M8

CARLO GAVAZZI



- Stainless steel housings
- Sensing distance: 0.8 - 1 mm
- Power supply: 10 to 30 VDC
- Output: Transistor NPN or PNP, make switching
- For flush mounting
- 2 m silicone cable

Product Description

Inductive proximity sensor with transistor output in M5 and M8 stainless steel housing for flush mounting in metal. Output configuration for NPN/PNP with NO as standard. Connection with 2 m silicone cable.

Ordering Key

IA 05 BSF 08 NO HT-K

Type _____
Housing style _____
Housing size _____
Housing material _____
Housing length _____
Detection principle _____
Sensing distance _____
Output type _____
Output configuration _____
High temperature _____

Type Selection

| Rated operating dist. (S _n) | Connection type | Housing dimensions | Ordering no. Transistor NPN Normally open | Ordering no. Transistor PNP Normally open |
|---|-----------------|--------------------|---|---|
| 0.8 mm | Cable, 2 m | M5 | IA 05 BSF 08 NOHT-K | IA 05 BSF 08 POHT-K |
| 1.0 mm | Cable, 2 m | M8 | IA 08 BSF 10 NOHT-K | IA 08 BSF 10 POHT-K |


All types for flush mounting in metal

Specifications


| | | | |
|--|--|-----------------------------|---------------------------------|
| Rated operational volt. (U_B) | 10 to 30 VDC (ripple included) | Ambient temperature | |
| Ripple | ≤ 10% | Operating | -25° to +120°C (-13° to +248°F) |
| Rated operational current (I_o) | | Storage | -30° to +125°C (-22° to +257°F) |
| Continuous | ≤ 50 mA @ + 25°C (+75°F) | Degree of protection | IP 67 (Nema 1, 3, 4, 6, 13) |
| No-load supply current (I_o) | ≤ 5 mA (ON) | Housing material | Stainless steel |
| Voltage drop (U_d) | < 3,0 V (@ I _{max}) | CE-marking | Yes |
| Frequency of op. cycles (f) | Ø5: 3 kHz Ø8: 2 kHz | Connection | Cable, silicone, 2 m, AWG 26 |
| Effective operating dist. (S_r) | 0.9 x S _n ≤ S _r ≤ 1.1 x S _n | | |
| Usable operating dist. (S_u) | 0.85 x S _r ≤ S _u ≤ 1.15 x S _r | | |



Dimensions



Wiring Diagrams



Installation Hints

| | | | |
|--|--|--|---|
| <p><i>To avoid interference from inductive voltage/current peaks, separate the prox. switch power cables from any other power cables, e.g. motor, contactor or solenoid cables</i></p> | <p><i>Relief of cable strain</i></p> <div><p>Incorrect</p><p>Correct</p></div> <p>The cable should not be pulled</p> | <p><i>Protection of the sensing face</i></p> <p>A proximity switch should not serve as mechanical stop</p> | <p><i>Switch mounted on mobile carrier</i></p> <p>Any repetitive flexing of the cable should be avoided</p> |
|--|--|--|---|