

4-Serial/1-Parallel Port PCIe Adapter

User Manual

Ver. 1.00

**All brand names and trademarks are properties of their
respective owners.**

Features and Benefits

- Features
- Compliant with PCI Express Base Specification 1.1
 - Supports 4 x UART serial port
 - Built-in 16C450/550 compatible UART
 - On chip 256 byte FIFOs in transmit and receive path of each serial port
 - Serial data transfer rate up to 230400bps
 - Supports Standard Parallel Port (SPP), Enhanced Parallel (EPP) & Enhanced Capability Port (ECP)
 - Parallel data transfer rate up to 1.5Mbps
- Bus
- PCI-Express x1
- Connectors
- 4 x DB9 male serial connectors
 - 1 x DB25 female parallel connector

System Requirements

- Windows® XP/Vista/7 (32/64 bit)
- PCI Express-enabled system with an available PCI Express slot

Package Contents

- 1 x 4-Serial/1-Parallel Port PCIe Adapter
- 1 x Bracket with two DB9 male serial ports
- 1 x Bracket with one DB25 female parallel port
- 1 x Driver CD
- 1 x User Manual

Hardware Installation

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCIe slot.
4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

Driver Installation

Put the driver CD in your CD-ROM drive. The CD-ROM will start automatically. Click "Install Driver" to start the installation. Follow the

instructions on screen to install the driver. After driver installation is complete, you must restart your computer.