



**Series 80 Mighty Mouse
Contacts and Tools
Jam Nut Tightening Tools
Connector Holding Fixtures**

Spanner Tool for Tightening Series 80 Jam Nuts

Use these tools to tighten Series 80 jam nuts. 1/4" or 3/8" square drive for use with torque wrenches. Heat-treated steel, nickel plated.



| Shell Size | Spanner Tool Part Number | | | | | |
|------------|--------------------------|------------|------------|---------------------|---------------------|------------|
| | Series 800 | Series 801 | Series 803 | Series 804 Style 07 | Series 804 Style 00 | Series 805 |
| 5 | 600-146-01 | 600-146-02 | 600-137-05 | 600-146-03 | 600-147-5 | — |
| 6 | 600-146-02 | 600-146-03 | 600-137-06 | 600-146-04 | 600-147-6 | — |
| 7 | 600-146-03 | 600-146-05 | 600-137-07 | 600-146-06 | 600-147-7 | — |
| 8 | 600-146-04 | 600-146-05 | 600-137-08 | 600-146-06 | 600-147-7 | 600-154-08 |
| 9 | 600-146-05 | 600-146-06 | 600-137-09 | 600-146-07 | 600-147-9 | 600-154-09 |
| 10 | 600-146-06 | 600-146-07 | 600-137-10 | 600-146-08 | 600-147-10 | 600-154-09 |
| 11 | — | — | — | — | — | 600-154-11 |
| 12 | 600-146-08 | — | 600-137-12 | 600-146-10 | 600-147-12 | 600-154-12 |
| 13 | — | 600-146-10 | — | — | — | — |
| 14 | 600-146-10 | — | 600-137-14 | 600-146-12 | 600-147-14 | — |
| 15 | 600-146-11 | — | 600-137-15 | 600-146-13 | 600-147-15 | 600-154-15 |
| 16 | — | 600-146-13 | — | — | — | — |
| 17 | — | 600-146-14 | — | — | — | — |
| 18 | — | — | — | — | — | 600-154-18 |
| 19 | — | — | — | — | — | 600-154-19 |
| 21 | — | 600-146-17 | — | — | — | — |
| 23 | — | — | — | — | — | 600-154-23 |

Connector Holding Tool for Tightening Backshells and Accessories



1 Plug tool for holding Series 80 plug connectors. Heat-treated steel, nickel plated.

2 Receptacle tool for holding Series 80 receptacle connectors. Heat-treated steel, nickel plated.



| Shell Size | Holding Tool Part Number (Add P or R) | | | | | | | | |
|------------|---------------------------------------|---|-------------|---|------------|---|------------|------------|------------|
| | Series 800 | | Series 801 | | Series 803 | | Series 804 | Series 805 | |
| 5 | 600M005-05 | ★ | 600MM005-05 | ◆ | 600-140-5 | ★ | 600-141-5 | ■ | — |
| 6 | 600M005-06 | ★ | 600MM005-06 | ◆ | 600-140-6 | ★ | 600-141-6 | ■ | — |
| 7 | 600M005-07 | ★ | 600MM005-07 | ◆ | 600-140-7 | ★ | 600-141-7 | ■ | — |
| 8 | 600M005-08 | ★ | 600MM005-08 | ◆ | 600-140-8 | ★ | 600-141-8 | ■ | 600-155-8 |
| 9 | 600M005-09 | ★ | 600MM005-09 | ◆ | 600-140-9 | ★ | 600-141-9 | ■ | 600-155-9 |
| 10 | 600M005-10 | ★ | 600MM005-10 | ◆ | 600-140-10 | ★ | 600-141-10 | ■ | 600-155-10 |
| 11 | — | — | — | — | — | — | — | — | 600-155-11 |
| 12 | 600M005-12 | ★ | — | — | 600-140-12 | ★ | 600-141-12 | ■ | 600-155-12 |
| 13 | — | — | 600MM005-13 | ◆ | — | — | — | — | — |
| 14 | — | — | — | — | 600-140-14 | ★ | 600-141-14 | ■ | — |
| 15 | — | — | — | — | 600-140-15 | ★ | 600-141-15 | ■ | 600-155-15 |
| 16 | — | — | 600MM005-16 | ◆ | — | — | — | — | — |
| 17 | — | — | 600MM005-17 | ◆ | — | — | — | — | — |
| 18 | — | — | — | — | — | — | — | — | 600-155-18 |
| 19 | — | — | — | — | — | — | — | — | 600-155-19 |
| 21 | — | — | 600MM005-21 | ◆ | — | — | — | — | — |
| 23 | — | — | — | — | — | — | — | — | 600-155-23 |

★ Add **P** for plug holder or **R** for receptacle holder, followed by polarizing position (**N,X,Y,Z**).
 ◆ Add **P** for plug holder or **R** for receptacle holder, followed by polarizing position (**A,B,C,D**).
 ■ Add **P** for plug holder or **R** for receptacle holder.

Dimensions in inches (millimeters) and are subject to change without notice.