

Description

This reusable tool is used to properly space the code wheel from the encoder base.



Ordering Information

SPACER -

Type

A2 =

E2 =

E3S =

E3 (

E3L =

E3 (> or = 12mm bore)

E4 =

E4P =

E5 =

E6S =E6 (

E6L =

E6 (> or = 12mm bore)

E7P =

E8P =

Notes

- US Digital warrants its products against defects in materials and workmanship for two years. See complete warranty for details.

Base Pricing

Quantity	Price
1	\$0.95
10	\$0.89

For volume discounts, please contact us at sales@usdigital.com or 800.736.0194.