



User's Guide

Table of Contents

04 Get Started

- 04 What's included
- 05 Understanding how your BABOLAT PLAY racket works

06 Setting up Play on a computer

- 06 System requirements
- 06 Connecting the racket using a PC/Mac and a USB cable
- 07 Profile set up
- 07 Installing BABOLAT Connect software on a PC/Mac
- 08 Associating and synchronizing your racket and computer

09 Setting up Play on a mobile device

- 09 Mobile device requirements
- 09 Installing BABOLAT PLAY app on a mobile device
- 10 Pairing your racket to a mobile device
- 11 Syncing your racket to a mobile device

12 Settings

- 12 Confidentiality
- 12 Choosing a coach
- 12 Autoshare with Facebook

13 Using BABOLAT PLAY

- 13 Recording and downloading your sessions
- 14 The PULSE – How does it Work?
- 15 Analyze – How does it Work?
 - 15 Shot Breakdown
 - 16 Serves
 - 16 Serves & Spin
 - 16 Impact Ball Locator
 - 17 Tagging a session
- 18 Evolution & custom feature on the website
- 19 Skills – How does it Work?
- 19 Compare and share – How does it work?

20 Tips & Advice

- 20 Lending your racket
- 20 Merging two sessions
- 21 Sweeping action on a mobile device

22 BABOLAT PLAY and Coaching

25 Maintenance

26 Technical specifications

27 Service & Support

29 Compliance information

32 Contact

Getting Started

What's included?

Your BABOLAT PLAY pack includes the following:

1. BABOLAT PLAY travel cover
2. BABOLAT PLAY racket
3. BABOLAT PLAY USB cable



Figure 1

Your BABOLAT PLAY racket has sensors embedded within the handle. These sensors measure your game and sync wirelessly to a mobile device or with a USB cable to your computer.

Understanding how your BABOLAT PLAY racket works:

Understanding your BABOLAT PLAY racket's main functions before attempting to install BABOLAT Play software onto your computer or the application onto a mobile device, is essential to fully benefit from the experience.





Mode/State	Activate	Response
Off	Default Mode	No light
Switch On (measuring)	Press and hold this button  for 1 second	Blue light turns on and flashes slowly
Split a playing session (1 st set, 2 nd set...)	Press this button  quickly (less than 1 second)	Red light turns on for 1.5 seconds
Switch Bluetooth on (measure is off)	Press and hold this button  for 2 seconds	Purple light turns on and starts flashing slowly
Switch Off	Press and hold this button for  1.5 seconds	Blue light turns off
	The racket switches off automatically if no motion is detected for 10 minutes	
Alert	Activate	Response
Low Battery	Displayed automatically when racket has 10% battery life remaining	Red LED blinks every 2 seconds
Charging	Plug into charger and connect to power source	Red LED turns on
Charging complete	Charge to completion	Green LED turns on
Memory full	Displayed automatically when racket memory is full at 95% (Synchronization is needed...)	White LED turns on and flashes

Figure 2

Setting up BABOLAT PLAY on a computer:

System requirements:

To use BABOLAT PLAY on a computer, you must have the following system requirements:



A Macintosh with
built-in USB; Mac OS
X v10.5.8 or later



Windows 7, 8
Windows Vista or
Windows XP

Internet access (Broadband recommended; fees may apply).

Web browser: Internet Explorer 8+, Firefox, Safari 5+, Chrome.

For a complete list of compatible devices, visit: www.babolatPlay.com/support

To set up your BABOLAT PLAY racket with a computer, you'll need the Play racket, the USB cable provided in your pack and a computer, Mac or PC, with a USB drive.

Connecting the racket using a PC/Mac and a USB cable:

1. Turn on the racket (figure 1)
2. Open the butt cap of the racket (figure 3)
3. Connect the racket to the computer using the USB cable. Insert the USB cable into your racket and then connect the other end of the cable into your computer. Your racket will be recognized as a USB drive. Inside the USB drive, select the Play link to be directed to BABOLAT PLAY website <http://www.babolatplay.com>.




Figure 3

Profile set up:


When the BABOLAT PLAY website opens, you'll need to **click on the Join button** at the top of the page to create your personal account and profile using Facebook Connect or your email address. To create your account, set up your username, password and fill in personal details like your first name, last name and whether you are left or right handed. This information personalizes your BABOLAT PLAY experience and improves the accuracy of your data.

Installing BABOLAT Connect software on a PC/Mac:

Once your profile is finalized, you'll need to **click on the synchronize button on the top right-hand corner of the webpage**. A Tutorial window will appear instructing you on how to download the BABOLAT Connect software (figure 4).

SYNCHRONIZE

You are entering the world of Babolat Play. You just need to follow a few steps before stepping out on the tennis court!



- 1- DOWNLOAD BABOLAT CONNECT**
Click on the PC or MAC button below. The software setup will be downloaded to your computer.
- 2- INSTALL AND LOGIN**
Launch this software setup to install Babolat Connect. Complete the installation process and proceed to log in on the Babolat Connect window.
- 3- SYNCHRONIZE YOUR RACKET**
Make sure that your racket is plugged with the USB cable. When racket logo lightens, click on the synchronize button. Let's play.

[DOWNLOAD FOR MAC \(22MD\)](#) [DOWNLOAD FOR WINDOWS \(31MD\)](#)

Figure 4

The free BABOLAT Connect software allows you to sync stored data from your racket to your babolatPlay.com Dashboard. **If you haven't created your account yet**, you can do so whilst installing the BABOLAT Connect software:

1. Go to <http://www.babolatPlay.com>
2. On the homepage of the website, scroll down to the bottom of the page.



Figure 5

3. Click on either the Mac or PC icons (figure 5)
4. Follow the instructions and **download** the BABOLAT connect software.

NOTE: See www.babolatplay.com/support for tutorial videos if you need more help.

Associating and Synchronizing your racket and computer:

Once the BABOLAT connect software is installed on your computer, you can **login with your own BABOLAT PLAY account**. This will allow you to sync your data

You will need to **login to your account**.

1. You will then be asked to **synchronize your racket (figure 6)**. Once your synchronization is complete, a message will invite you to Play. You can then **disconnect your racket from** your computer, sign out and Play. Before you start to Play, check to make sure that your racket is on: the blue light should be flashing. If not, press the button for 2 seconds. You are now ready to record your game.

NOTE: BABOLAT connect software can only be used on a computer with a USB cable.




Figure 6

Setting up Play on a mobile device:

Mobile device requirements:

BABOLAT PLAY is capable of being set up and syncing with mobile devices that support Bluetooth 2.1 technology.

For a complete list of compatible mobile devices, visit: www.babolatPlay.com/support

Installing BABOLAT PLAY App on a mobile device:

The free BABOLAT PLAY App allows you to sync stored data from your racket to your babolatplay.com Dashboard. To set up your BABOLAT PLAY racket with an iPhone or android, you'll need the PLAY racket and a compatible iPhone or android:

1. **Download and install** the BABOLAT PLAY App from the Apple Store (iOS) or Google Play Store (Android).
2. Once the App. is installed, open it. **Select Get Started.**
3. You'll then need to create your personal account and profile **using Facebook Connect or your email address.** Set up your username, password and fill in personal details like first name, last name, left or right hand (figure 7). This information personalizes your BABOLAT PLAY experience and improves the accuracy of your data.



The screenshot shows a mobile app interface for creating a profile. At the top, there's a back arrow and the title 'PROFILE'. Below that is a placeholder for a profile picture. The form consists of several rows, each with a label on the left and a value on the right:

Name	Baptiste
First Name	Dumas
Birth date	29/04/1989
Zip code	75008
City	Paris
Country	France
Hand	Right
Account type	Player

Below the form are three checkboxes:

- I accept [terms and conditions](#)
- I accept to receive emails about the latest Babolat news
- I accept to receive emails about the latest Play news


At the bottom is a large orange button labeled 'LOGIN'.

Figure 7

Pairing your racket to a mobile device:

Once the BABOLAT PLAY App is installed on your mobile device, you can pair your own mobile to your BABOLAT PLAY account. This will allow you to sync your data and manage your racket's device settings:

1. First, go to your iPhone/android, and select settings. Then on the menu, press Bluetooth.
2. First make sure your Bluetooth is activated (figure 8). If it is not, slide the button to the ON mode



Android



iOS

Figure 8

3. Next, you will need to turn on the racket's Bluetooth by pressing on the Bluetooth button located on the butt cap of your racket. A purple light should be flashing when the Bluetooth is turned on. Your racket is now in discovering mode. See figure 1 for instructions if necessary.
4. Soon, the BABOLAT Play racket should appear in the list of Bluetooth devices. Select it. The pairing will take place and the racket will show as paired.

NOTE: See www.babolatPlay.com/support for tutorial videos if you need more help.

Syncing your racket to a mobile:

Next, open the BABOLAT PLAY App and login if necessary. You will then have to **press on the racket symbol on the top right-hand corner of the app screen** to start synchronization (figure 9).




figure 9

You can check your battery level indicator on the screen of your mobile (figure 10).



figure 10

Once your synchronization is complete, a message will invite you to Play. Before you start to Play, check to make sure your racket is on: the blue light should be flashing. If not, press the button for 2 seconds. You are now ready to Play and record your game.

Settings

Confidentiality

In the settings menu of the website and the App, you can select the level of confidentiality of your PLAY profile to be shared with the PLAY community. There are 3 possible solutions: closed profile (share nothing), restricted sharing (just the Pulse), or open (share everything).

Declaring a coach

If you have a coach in the PLAY community, you can declare him by clicking on yes or no and then select his name in the menu bar (figure 11).



The image shows a user interface for declaring a coach. At the top, there is a question "Have you got a coach?" with two radio button options: "Yes" (which is selected and highlighted in green) and "No". Below this is a text input field labeled "Coach name" with a "+ Add a coach" button to its right. A dropdown menu is open, showing a person icon and the text "PICK A COACH" above a search input field with a magnifying glass icon.

Figure 11

Autoshare with Facebook

If your account is linked to Facebook, you can choose to share or not share your information in the settings menu by clicking on either yes or no.

Using BABOLAT PLAY

In order to get the most out of your BABOLAT PLAY experience, make sure you read through the tutorials available on the application, the website and in this User's Guide.

Video Tutorials are available on the website by [clicking on? HELP CENTER](#) (figure 12).




Figure 12

On the mobile App, the tutorials open automatically when you launch the App for the first time. If you want to consult them again, [go to Help](#) on the dashboard of the App.

Recording and Downloading your sessions:

You just have to turn on your racket to record a session. Remember to turn off your racket at the end of a session. If you forget, it will automatically switch off after 5 minutes.

Note: You can record consecutive sessions by turning the racket on and off as many times as you want.

You can download your sessions using the Play App or a computer:

1. **Using the application:** the Bluetooth on your Smartphone should be turned on (figure 8), and your racket, switch its Bluetooth mode on (see figure 1). Played sessions will be downloaded automatically if the application is open.
2. **Using a computer:** you must first install the BABOLAT Connect Software (page 7). Once you plug the racket with the USB cable into your computer, the BABOLAT Connect software will open and guide you to download your session.



The PULSE – How does it Work?




Figure 13

Overview

The Pulse is a visualization of **your Playing style** and your overall ranking in the BABOLAT PLAY tennis community with your Pulse Average Score. The Pulse is based on 3 aspects: technique, Power and Endurance. After 2 validated sessions, your Pulse starts to appear. It will be completely active after 6 sessions (figure 13).

Your Pulse beats accordingly with your tennis Play frequency. The **more you play & synchronize on a regular basis**, the more rapidly your Pulse beats. It will also change color whenever you unlock new skills. If you stop Playing, the beat rate will slow down gradually.

The grey shape with the dash outline is your last validated session. The average score indicates your overall Pulse rating.

Note: If you haven't played for more than 3 months, your Pulse will stop beating. Getting back onto the court will reactivate your Pulse. Take care of your Pulse, play often.

The **endurance index** is linked with your Play frequency and to the energy you use during each session. It indicates your ability to sustain a long and strong effort.

The **technique index** is based on your ability to consistently hit the ball in the Sweetspot for each type of shot.

The **power index** is the mean value of the power for all your shots. Every shot is counted.



Analyze – How does it Work?




Figure 14

Overview

Find all your game sessions on the activity wall. After downloading a session from your racket, they appear directly on your activity wall. **You must validate your sessions to update your statistics** (figure 14).

You can define each session as a match or a training session; track your tennis score and more. Each validated session reactivates your Pulse, develops your skills and updates your records.

Note: Once a session is validated, it shows up in your personal statistics and cannot be erased.




Figure 15

Shot Breakdown

Shot breakdown tells you how many shots you've hit in each session for each different stroke type.

Figure 15 shows that 81 forehands were hit out of a total number of 179 shots. In other words, 45% of the total number of shots was forehands.



Figure 16

Serves

You can also analyze your First Serves and Second Serves. The gauge in figure 16 indicates the power level of your last First serve or Second serve, as well as your maximum Power Level achieved during the overall session. This will help you stay on top and maximize your power capacity every time you serve.




Figure 17

Serves & Spin

You can go even deeper by checking out whether your serves had spin or were flat. For example in figure 17, it shows out of 33 first serves, 17 had spin and 16 were flat. The Spin effect rating underneath the gauge refers to your average amount of spin. It also indicates your % power level explained in figure 16.




Figure 18

Ball Impact Locator

Are you consistent in locating the ball in the same place on your racket? You now have access to this information. Figure 18 shows that out of 101 shots, 19 were on the Sweet spot, 32 on the right hand side etc....

Tagging a session:

The Tag feature allows you to **split your game session into sequences**. By pressing the tag button on your racket's butt cap (see figure 1), you can review your match set by set or analyze a training session in more detail with the following information: number of shots, average power, energy used, playing time and regularity (figure 19).



Figure 19

The Tag feature is particularly useful **for working on consistency i.e. your ability to reproduce a given shot over and over again**. The more you master your technique, the more consistent your shots will be. This index is adapted to training or drills, when the goal is to reproduce one particular shot consistently (for example, on a service drill).

Evolution on the website:

In the Evolution feature on the website, you can visualize your performance, either in simple mode (figure 20) or in custom mode (figure 21). Custom mode allows you to personalize the amount of information you want to display at any one time. You can also customize the period of time for which you wish to review your evolution; weekly, monthly or even yearly.




Figure 20




Figure 21



Skills – How does it Work?

Your Skills level indicates **your achievements within the PLAY experience and depends on how hard you've played and practiced since the beginning**. Each shot played with your racket is counted and fills in a corresponding gauge. When all your shot gauges reach 100%, you get to the next Skills level. Note also that a varied style of play will fill each gauge more quickly and bring you more rapidly to the next level.

In Skills you also get an easy look into what styles you often use and which ones you haven't implemented in your game. Remember, the more diverse your style is, the tougher an opponent you become.

Your skills level depends also on your frequency of play. If you stop playing for a long time, for example, then your skills level will start to decrease.



Compare yourself to the BABOLAT Play Community:

The ranking of Players within the Play community is based on your Pulse's average score. **For the first time, you will be able to compare your tennis with other Players within the community.**

You can also find other Play Players to be a partner or an opponent and then follow them in the community. You can search all Play Players, Facebook friends who have a Play account, or within the BABOLAT pro team.

You are free at anytime to **Follow** or **Unfollow** friends within the Play community.

Your ranking in the Play community will be more accurate if you chose your own category i.e. Players of the same age and sex.

With the **Versus** feature in Community, you can **compare your Pulse with another player's Pulse** within the Play community (figure 22). To do this using a Smartphone, just turn it sideways.




Figure 22

Tips & Advice

Lending your racket:

If you plan on lending your racket, you must synchronize and download your data beforehand (figure 23)



Figure 23

Merging sessions:


If you decide to take a break from playing for more than 15 minutes or if you have to replace your strings, your racket will turn off. Your racket will think your session has finished. If you start playing again, you have the possibility of merging the new session with the previous one.

To do this, [click on the undefined session in the app for just over a second or by using your mouse on the Website](#). It will become highlighted. Drag and drop it onto the previous session to merge the two together (figure 24). Merging sessions can also be done if a player has more than one PLAY racket paired to the same account. If your sessions are 5 hours apart, you can no longer merge them.


Resetting Your Racket

If your racket appears to be frozen, we advise you carry out a racket reset. To do this, [you firstly need to open the butt cap trap, take a thin object, insert it in the hole and press down](#).





App



Website

Figure 24

Sweeping action using the mobile app:

By sweeping your finger across your mobile device, this will allow you to either **define your session as a favorite**, **share it** or **put it in the trash can** (figure 25).




Figure 25

BABOLAT PLAY and Coaching:

BABOLAT PLAY is an exciting tool for those coaches looking for a new way of monitoring their pupil's performance. With BABOLAT PLAY, you will have access to factual information designed to help you learn more about your pupil's game, wherever you are and whenever you want. Monitoring Player performance becomes possible not only after training sessions but also after matches. PLAY is authorized in competition tennis and approved for by the International Tennis Federation. The ITF have created a new rule within the Rules Of Tennis, Rule 31. This rule lays down the boundaries with which Player Analysis Technology can be used in competition tennis.

The following guidelines will help you, as a Coach get the most out of BABOLAT PLAY.

Creating a Coach account:

You can create your own account on the BABOLAT PLAY website **with or without a Play Racket**. Creating your account will enable you to access your pupil's data.

When creating your profile, you'll be asked whether you are a Player or a Player/Coach. [Click on player/coach](#).

Using Coach Mode available at www.babolatplay.com:

BABOLAT PLAY includes a Coach Mode feature. The Coach Mode allows you to access each of your pupil's data. In order for you to access your pupil's data, you first need to ask each one of **your pupils to declare they have a coach** in the settings menu (figure 26).




Figure 26

The Coach Mode allows you to visualize each of your pupil's performance; ranking in the Play community, total number of shots, last record and more (figure 27).



Figure 27

Evolution and custom feature on the website:

In the Evolution feature on the website, you can visualize your pupil's performance, either in simple mode (figure 28) or in custom mode (figure 29). Custom mode allows you to personalize the amount of information you want to display at any one time. You can also customize the period of time for which you wish to review their evolution; weekly, monthly or even yearly.




Figure 28




Figure 29

Downloading:

In Evolution, you can download or print out data graphs from a given session and share with students.

Tagging in Analyze



The Tag feature allows you to **divide your pupil's game sessions into sequences** (figure 30). By pressing the tag button on their racket's butt cap (see figure 1), you can review the match set by set or analyze a training session in more detail with the following information: number of shots, average power, energy used, playing time and shot consistency.

By using the Tag feature, your pupils will be able to improve their consistency i.e. their ability to reproduce a given shot over and over again. The more they master their technique, the more consistent their shots will be. This index is adapted to training or drills, when the goal is to reproduce one particular shot consistently (for example, on a service drill).




Figure 30

Maintenance

Charging the racket

Charging your battery can be done at any time. To do this, you can either use a USB port on a computer with the USB cable provided, or by plugging the USB cable into a wall plug equipped with a USB port. It will take 3 hours to fully charge your battery.

Caring for your BABOLAT PLAY racket

It is not advisable to use your PLAY racket when it's raining heavily. Never put your BABOLAT PLAY racket in water. It will damage the electronic circuitry and sensors.

Avoid dropping the racket on hard surfaces. This could affect the accuracy of the electronic circuitry inside.

Avoid opening the butt cap trap on a clay court; dust may enter the USB port which could interfere with its proper functioning.

Avoid extreme temperatures, don't store your racket in direct sunlight (on the back shelf of a car for example) or in below 0°C/32°F.

Customization

Do not attempt to open the handle of your racket in order to carry out customization. You can however add lead tape to the head of your racket in order to change its weight.

Note: Power is calculated on the basis of the speed of the racket head. Adding weight to the racket could slow down the calculation of the racket head speed.

Updating BABOLAT PLAY application

When the BABOLAT PLAY app update is available, a message will appear on your mobile device. [Click-on the BABOLAT PLAY app icon on your mobile](#) to start the updating process of the software.

Updating BABOLAT PLAY software

When BABOLAT connect software updates are available, a message in the software will say, "A newer version of BABOLAT connect software is available, would you like to [download and install it now?](#)" [Clicking the update button will update the software.](#)

Updating BABOLAT PLAY racket

Each time you plug your BABOLAT PLAY racket into the USB port on your computer or connect to your mobile app via Bluetooth, BABOLAT PLAY will check for new firmware (updates for your BABOLAT PLAY racket). When new updates are available, a message in BABOLAT connect will prompt you to accept the update.

Technical specifications

Autonomy

The high performance Lithium battery allows for 6 hours of playing time with a memory capacity of on average of 150 hours of tennis.

You can check your BABOLAT PLAY battery level by logging into your account and synchronizing. A Battery indicator will appear indicating its level of charge.

Racket specifications:

Headsize: 645cm²
Weight: 300g/10.6oz
Balance: 320mm
Rigidity: 72ra
Length: 645mm/27in
Grip: Syntec pro
Grip Size: 1 to 5
Composition: Graphite

Sensors:

A Built-in accelerometer and gyrometer measure speed and motion whenever you play a session.

Battery:

Type: 1 lithium Polymer battery
Nominal voltage: 3.7V

Water resistance:

The BABOLAT PLAY racket is water resistant. It's safe to play in light rain.

Packaging:

Travel bag: Polyester 100%, Polyurethane 100%, Foam 100%
PVC free
Pack USB: Cardboard

Service & Support

If you have any questions? For service and support tutorials, FAQs or Hotline details go to www.babolatplay.com/support.

Return policy and Warranty

ONE-YEAR LIMITED PRODUCT WARRANTY

BABOLAT warrants to the original purchaser that the BABOLAT PLAY PURE DRIVE (the "Product") is free from defects in material or workmanship, under normal use for a period of one year from the date of purchase.

This warranty is only valid for purchases made directly from authorized BABOLAT dealers. Authorized BABOLAT dealers can be found at www.babolat.com. BABOLAT will not accept any returns directly from consumers.

The warranty is nontransferable.

This warranty includes sensors. However, BABOLAT does not warrant that the electronic or software operation of the Product will be uninterrupted or error-free, or that all such errors may be corrected.

BABOLAT is not responsible for any loss of software programs, data or other information contained on the storage media or any other part of the serviced products.

BABOLAT disclaims the provision of or failure to provide support or other services, information, software, and related content through the product.

This Limited Warranty does not apply to:

- (a) protective coatings that are designed to diminish over time, unless failure has occurred due to a defect in materials or workmanship including but not limited to scratches, dents and broken plastic on ports;
- (b) damage caused by use with another product;
- (c) damage caused by accident, abuse, misuse, liquid contact, fire, or other external cause;
- (d) damage caused by operating the Product outside BABOLAT's published guidelines;
- (e) Products which had their electronic module housings opened or otherwise tampered with; and
- (f) defects caused by normal wear and tear or otherwise due to the normal aging of the Product, or if any serial number has been removed or defaced from the Product.
- (g) Consumable parts or accessories, such as batteries and USB cable, unless damage has occurred due to a defect in materials or workmanship.

If the Product is defective, return it with a legible copy of the proof of purchase and a written description of the problem to the place of purchase within one year of the date of purchase. Authorized BABOLAT dealer will then contact BABOLAT to process the warranty return or service. You are responsible for any necessary shipping charges for returned or replaced products.

BABOLAT will repair or replace any product found to be defective at its discretion. Any replacement under this warranty will only be made with the same or similar product of the same or similar value and will not include cash, credits, or other types of products.

BABOLAT strives to provide a timely warranty process and will work to perform its obligations under this warranty within 30 days, under normal conditions, after the warranted product is returned to an authorized BABOLAT dealer as set forth above. This period may be extended if replacement products are out of stock or other unusual circumstances require longer. All repaired or replacement product will be covered for one year from the date of the original purchase.

BABOLAT shall not be liable for incidental or consequential damages, during warranty service the contents of the storage media will be deleted and reformatted.

If BABOLAT determines that the problem with the Product is not covered under this Limited Warranty, we will notify you and inform you of service or replacement alternatives that are available to you on a fee basis.

Repair or replacement as provided under this warranty is the exclusive remedy of the consumer, except for the warranties contained in this limited warranty, BABOLAT makes no other warranty of any kind, express or implied, in fact or by law, whether of merchantability, fitness for any particular purpose or otherwise. Your sole and exclusive remedy under this limited warranty shall be product repair or replacement as provided herein.

In the event of any dispute regarding the Product, the Purchaser and BABOLAT agree to resolve any Claims only by BINDING ARBITRATION that must be brought in Denver, Colorado. Such arbitration will be conducted under the Streamlined Arbitration Rules of JAMS. For the purposes of this section, references to "Purchaser" include the original purchaser, their family members, beneficiaries, and assigns, and references to "Claim" shall include any dispute, claim or controversy arising from or relating to: (1) the Product, whether based in contract; tort; fraud; misrepresentation; state or federal statute, regulation, ordinance; or any other legal or equitable theory, and (2) this Limited Warranty. There shall be no right or authority for any Claims to be arbitrated on a class action basis. This Dispute Resolution agreement is part of a transaction involving interstate commerce and is governed by the Federal Arbitration Act, which governs its enforcement and interpretation.

No other person or company is authorized to change this Limited Warranty, and your dealer is solely responsible for any other additional warranties. Some states and countries do not allow limitation on consequential damages or how long an implied warranty lasts, or exclusion of all or certain types of damages, so the above limitations may not apply to you. This Limited Warranty gives you specific legal rights, and you may also have other additional rights, which vary from countries. The foregoing is without prejudice to other legal rights that may arise under applicable national legislation.

BABOLAT VS North America, Inc.
1775 Cherry Street, Suite 100
Louisville, CO 80027
aftersales@babolat.com

Document last revision: October 18th, 2013

Compliance information



This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications made to this equipment not expressly approved by BABOLAT may void the FCC authorization to operate this equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.


Compliance Information

Declaration of Conformity for BABOLAT Play Pure Drive

We, BABOLAT VS of 93 rue André Bollier – B.P 7123 – 69 353 LYON Cedex 07 - France, declare under our sole responsibility that our connected racket, BABOLAT Play Pure Drive, and in combination with our accessories, to which this declaration relates is in conformity with the appropriate standards EN 60950-1:2006/A11:2009/A1:2010/AC:2011/A12:2011, EN 301 489-1 V1.9.2, EN 301 489-17 V2.2.1, EN 300 328 V1.8.1 and EN 62479:2010 following the provisions of the Radio Equipment and Telecommunication Terminal Equipment directive (1999/5/EC).

CE 0682

LYON, August 2013



P. VALADE
P. VALADE
11/07/2013

Patrick VALADE,
Product Director

This product conforms to the directive R&TTE **(1999/5/EC)**.

This product contains a battery that is not user accessible. Do not attempt to open the case, otherwise data may be lost and performance compromised. Substances contained in this product and/or its battery may damage the environment and/or human health if disposed of improperly. The wheeled bin on this product indicates that it should not be disposed of together with household waste. Please be responsible and take it to your nearest recycling collection point to ensure it is recycled. To locate your nearest collection point, contact the retailer where you made your purchase or your local municipality.

“Made for iPod” and “Made for iPhone” mean that an electronic accessory has been designed to connect specifically to iPod or iPhone, respectively, and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note that the use of this accessory with iPod or iPhone may affect wireless performance. iPhone, iPod and iPod touch are trademarks of Apple Inc., registered in the U.S. and other countries.

Compliance Information



Bluetooth version 2.1

BABOLAT Play Pure drive

Prior to use, please read the important information leaflet separately provided.

This User guide is published by BABOLAT or its local affiliated company, without any warranty.

Improvements and changes to this User guide necessitated by typographical errors, inaccuracies of current information, or improvements to programs and/or equipment, may be made by BABOLAT at any time and without notice. Such changes will, however, be incorporated into new editions of this User guide.

All rights reserved.

©BABOLAT, 2013

Publication number: 1258-0306.3

Interoperability and compatibility among Bluetooth™ devices varies. Device generally supports products utilizing Bluetooth spec. 1.2 or higher, and Headset or Hands free profile.

All product and company names mentioned herein are the trademarks or registered trademarks of their respective owners. Any rights not expressly granted herein are reserved.

All other trademarks are property of their respective owners.

Visit www.babolatplay.com for more information.

All illustrations are for illustration only and may not accurately depict the actual accessory.

Contact

BABOLAT VS North America, Inc.
1775 Cherry Street, Suite 100
Louisville, CO 80027

USA

Website: www.babolatplay.com

Email: support@babolat.com

Hotline: 001 877 316 9435