

---

---

**ENGLISH**

## Xbox 360 120GB Hard Drive

Thanks for choosing the Xbox 360 120GB Hard Drive. The Xbox 360 120GB Hard Drive lets you save games, save music and create custom playlists, download videos and other new content from Xbox Live®, and play original Xbox games. Your hard drive comes pre-loaded with high-definition bonus content and includes a software disc and transfer cable that let you move content from an Xbox 360 20GB Hard Drive to your new Xbox 360 120GB Hard Drive.



### **IMPORTANT**

If you want to transfer saved games and other content from your existing hard drive to your new 120-GB hard drive, do not attach the 120-GB hard drive to your Xbox 360 console until you have transferred the contents of your 20-GB hard drive according to the instructions below. Anything you store on the hard drive prior to content transfer will be lost.

The Xbox 360 120GB Hard Drive is for use exclusively with the Xbox 360™ video game and entertainment system.

For an easy, portable way to take your saved games or Xbox Live membership with you wherever you go, try the Xbox 360 Memory Unit (sold separately).

---

---

**NOTE**

Because the Xbox 360 system software uses some of the memory from the hard drive, less than the stated storage capacity will be available to the user.

** WARNING**

Before using this product, read this manual and the Xbox 360 console manuals for important safety and health information. Keep all manuals for future reference. For replacement manuals, go to [www.xbox.com/support](http://www.xbox.com/support) or call Xbox Customer Support (see “If You Need More Help”).

The limited warranty covering this product is contained in the Xbox 360 Warranty manual (Volume 2) and is available online at [www.xbox.com/support](http://www.xbox.com/support).

---

**TRANSFER CONTENT FROM AN EXISTING XBOX 360 HARD DRIVE**

Before attaching your new 120-GB hard drive, decide whether you want to perform a one-time transfer of all content from your existing hard drive. Whether you move your existing content or not, both drives are—and will remain, even after content transfer—fully compatible with your console. However, content can only ever be moved from the smaller drive to the larger one, and only once.

**NOTE**

If you intend to move content from your 20-GB hard drive, do not use the 120-GB hard drive prior to performing this procedure or you will lose whatever content you have put on it.

At the end of the transfer, your 120-GB hard drive will contain every file that could be transferred, including your saved games and content downloaded from Xbox Live.

---

---

Apart from this one-time option to move all content to your new drive, you cannot copy or move files from one hard drive to another, regardless of drive capacity. Except as detailed in the following procedure, only one hard drive may be connected to your console at a time.

#### **NOTE**

As with any data-transfer process, there is a risk that some or all of your data may become lost during the transfer process. If you proceed with the data-transfer process, you do so at your own risk and you agree that Microsoft is not liable for any loss of data resulting from the transfer process.

*To transfer content from your 20-GB hard drive to your 120-GB hard drive:*

- 1 Turn off your console with your existing hard drive still attached.
- 2 Disconnect all accessories from the console's controller ports.
- 3 Turn on your console. Connect and turn on a controller, which you'll need during content transfer.
- 4 Connect one end of the transfer cable to your 120-GB hard drive.
- 5 Connect the other end of the transfer cable to the console's rear USB port.
- 6 Insert the included Hard Drive Transfer Disc and follow the on-screen instructions.

#### **IMPORTANT**

Be sure to connect the transfer cable to the back port, not a port on the front of the console.




---

---

## IMPORTANT

The transfer cable connects to the 120-GB hard drive in only one orientation. Do not force the connector on. Connect the cable in the orientation shown.



## NOTES

- The Xbox 360 120GB Hard Drive transfer cable is not a PC accessory. It is intended only for connecting the Xbox 360 120GB Hard Drive to an Xbox 360 console for data transfer. Damage to your PC or other USB device could occur if you connect the transfer cable to such devices. The cable functions only when used with the supplied transfer software.
- The transfer cable is intended only for transferring data from your old hard drive to your new hard drive through your console. It is not intended for long-term connection to your console, nor is it intended for use with any other USB host or device. Dispose of the cable in accordance with the Disposal of Waste Electrical and Electronic Equipment guidelines below.
- If you are signed in to Xbox Live, the transfer process will sign you out.
- The Xbox Guide is not available during content transfer.
- If the transfer is interrupted for any reason, your content will remain on your existing 20-GB hard drive. You can restart the transfer process at any time prior to completion.
- To begin using your 120-GB hard drive after content transfer is complete, remove your 20-GB hard drive and attach your 120-GB hard drive as instructed in “Attach and Remove Your Hard Drive.”

---


## ATTACH AND REMOVE YOUR HARD DRIVE

---

If you're already using a 20-GB Xbox 360 Hard Drive, see "Transfer Content From an Existing Hard Drive" before attaching your 120-GB hard drive.

*To attach your hard drive:*

- 1 Turn off your console.
- 2 Remove the hard drive bay cover from your console.



- 3 Position the hard drive over the hard drive bay with the thin end (the front) pointed toward the front of the console and the thick end (the back) pointed toward the back of the console.
- 4 Place the back of the hard drive against the back of the hard drive bay. Make sure the ridge along the back of the hard drive is under the lip on the back of the hard drive bay.

- 5 Push the front end of the hard drive down until the tab clicks.



*To remove your hard drive:*

- 1 Turn off your console.
- 2 Press the tab on the front of the hard drive and lift the unit from the console.



### IMPORTANT

Avoid touching hard drive bay contacts or hard drive connector contacts with fingers or metal objects.

---

## PERSONALISE YOUR HARD DRIVE

---

You can personalise your hard drive by giving it a name.

*To give your hard drive a name:*

- 1 With the hard drive attached to the Xbox 360 console, select **System, Memory**.

- 2 Highlight your hard drive.
- 3 Choose **Device Options** and rename your hard drive.

Once your hard drive has been personalised, you can identify it by its new name.

---

## COPY OR DELETE SAVED ITEMS

---

You can move items on your hard drive to a memory unit. You can also free up space on your hard drive by deleting items.

*To move or delete an item from your hard drive:*

- 1 With the hard drive attached to the Xbox 360 console, select **System, Memory**.
- 2 Select your hard drive.
- 3 Choose the type of item, then the specific item that you want to move to another location or delete from the hard drive.

### NOTE

If you delete content originally included with your hard drive, it cannot be restored. Make sure you do not want to keep any content before deletion.

---

---

## TROUBLESHOOTING

---

If you encounter problems, try the possible solutions indicated below.

### Hard Drive Not a Listed Storage Device

If your hard drive is not listed as a storage device, try the following steps, in order.

- 1 Make sure the hard drive is fully inserted into the hard drive bay and looks level. Turn the console off, and then back on again.
- 2 Turn the console off and remove the hard drive. Turn the console on and then off again. Reattach the hard drive.

- 3 If possible, try the hard drive on another console, or try another hard drive on your console to pinpoint the problem.

### NOTE

Damaged hard drives will not show up in the Xbox Guide and could harm your Xbox 360 console. Hard drives that have been crushed, immersed in liquids, or exposed to intense heat may be damaged beyond use and will not show up in your list of storage devices.

## IF YOU NEED MORE HELP

---

Go to [www.xbox.com/support](http://www.xbox.com/support) or call Xbox Customer Support:

- Ireland: 1-800-509-186  
(TTY users: 1-800-509-197)
- United Kingdom: 0800-587-1102  
(TTY users: 0800-587-1103)
- South Africa: 0800-99-1550

Do not take your Xbox 360 console or its accessories to your retailer for repair or service unless instructed to do so by an Xbox Customer Support representative.



### **Do Not Attempt Repairs**

Do not attempt to take apart, service, or modify the Xbox 360 console, power supply, or its accessories in any way. Doing so could present the risk of serious injury or death from electric shock or fire, and it will void your warranty.

---

---

## **DISPOSAL OF WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT (WEEE) IN THE EUROPEAN UNION AND OTHER COUNTRIES WITH SEPARATE COLLECTION SYSTEMS**

This symbol on the product or its packaging means that this product must not be disposed of with your household waste. Instead, it is your responsibility to hand this over to an applicable collection point for the recycling of electrical and electronic equipment. This separate collection and recycling will help conserve natural resources and prevent potential negative consequences for human health and the environment, which inappropriate disposal could cause due to the possible presence of hazardous substances in electrical

and electronic equipment. For further information about where to drop off your electrical and electronic waste, please contact your local city/ municipality office, your household waste disposal service, or the shop where you purchased this product.



Contact

[weee@microsoft.com](mailto:weee@microsoft.com) for additional information on WEEE.

Hereby, Microsoft declares that this accessory is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC with regard to the EMC Directive 89/336/EEC.

---

---

## COPYRIGHT

---

Information in this document, including URL and other Internet Web site references, is subject to change without notice. Complying with all applicable copyright laws is the responsibility of the user. Without limiting the rights under copyright, no part of this document may be reproduced, stored in or introduced into a retrieval system, or transmitted in any form or by any means (electronic, mechanical, photocopying, recording, or otherwise), or for any purpose, without the express written permission of Microsoft Corporation.

Microsoft may have patents, patent applications, trademarks, copyrights, or other intellectual property rights covering subject matter in this document. Except as expressly provided in any written licence agreement from Microsoft, the furnishing of this document does not give you any licence to these patents, trademarks, copyrights, or other intellectual property.

© 2007 Microsoft Corporation. All rights reserved.

Microsoft, Xbox, Xbox 360, Xbox Live, Hoxic, the Xbox logos, and the Xbox Live logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.