

USB 3.0 to SATA 6G Cable

User Manual

Ver. 1.00

**All brand names and trademarks are properties of their
Respective owners.**

Features & Specifications

- Supports USB 3.0 SuperSpeed and USB 2.0
- Plug and Play, no driver installation
- Compliant to Universal Serial Bus 3.0 Specification, Revision 1.0
- Compliant to Universal Serial Bus Specification, Revision 2.0
- Compliant with Serial ATA Specification, Revision 3.0
- Bus bandwidth of Serial ATA up to 6Gbps
- Supports ATA/ATAPI Packet Command Set
- Support ATA/ATAPI LBA48 addressing mode
- Supports both SATA 2.5” and SATA 3.5” hard drives
- Supports SATA ATAPI Optical Drives
- LED to indicate driver power and activity

System Requirements


- Windows® XP/Vista/7/8/8.1 (32/64 bit)
- Available USB 2.0/3.0 port (USB 3.0 recommended)

Package Contents

- 1 x USB 3.0 to SATA 6G Cable
- 1 x User Manual
- 1 x Power Adapter (Optional)

Note: Contents may vary depending on country/market.

Hardware Description



Hardware Installation

1. Connect SATA data/power connector to 2.5" or 3.5" SATA device
2. Plug the power adapter into the power jack of the USB 3.0 to SATA 6G Cable.

3. Plug the USB 3.0 to SATA 6G cable into your computer's Superspeed USB 3.0 port.

Driver Installation

Windows will automatically detect and install the drivers for the USB 3.0 to SATA 6G Cable.