

USB 3.0 2.5” SATA 6G Hard Drive Enclosure

User Manual

Ver. 1.00

**All brand names and trademarks are properties of their
respective owners.**

Features

- Supports SuperSpeed USB 3.0 data rate up to 5Gb/s
- Plug and Play, no driver installation
- Compliant to Universal Serial Bus 3.0 Specification, Revision 1.0
- Compliant to Universal Serial Bus Specification, Revision 2.0
- Compliant with Serial ATA Specification, Revision 3.0
- Bus bandwidth of Serial ATA up to 6Gbps
- Supports 2.5" SATA hard drives
- LED to indicate drive power and activity

System Requirements

- Windows® XP/Vista/7 (32/64 bit)
- Available USB port

Package Contents

- 1 x USB 3.0 2.5" SATA 6G Hard Drive Enclosure
- 1 x User Manual
- 1 x USB 3.0 Cable


Note: Contents may vary depending on country/market.

Hardware Installation

1. Chassis Assembly

Disassemble the front panel from the housing by removing one screw from each side of the housing with a screwdriver, then remove the front panel

(See Figure A-C)



2. Hard Drive Installation

Connect the hard drive, install it and fasten the screws

(See Figure D-G)



Figure D



Figure E



Figure F



Figure G

Driver Installation

No driver installation is required for Windows operating systems, as this enclosure is natively supported, so the drivers are already installed.