

Order Codes

iTrack couplers

Supply coupler
Supply conduit (order supply coupler separately)
Linear coupler
L-coupler right
L-coupler left
T-coupler right
T-coupler left
X-coupler
Flex coupler

ITRSC
ITRCD1000
ITRIC
ITRLC/R
ITRLC/L
ITRTC/R
ITRTC/L
ITRXC
ITRFLEXC

Weights

iTrack couplers	KG
Supply coupler	0.20
Supply conduit	0.52
Linear coupler	0.05
L-coupler L/R	0.20
T-coupler L/R	0.30
X-coupler	0.40
Flex coupler	0.30



Supply Coupler



Supply Conduit



L-Coupler



T-Coupler



X-Coupler






Flex Coupler




Linear Coupler

Dimensions





Right

Left



Right

Left



 earth path - position indicated as viewed from above