

Home Media Server

© 2007 Nokia. All rights reserved.

Nokia, Nokia Connecting People, and Nseries are trademarks or registered trademarks of Nokia Corporation. Other product and company names mentioned herein may be trademarks or tradenames of their respective owners.

Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of Nokia is prohibited.

Nokia operates a policy of ongoing development. Nokia reserves the right to make changes and improvements to any of the products described in this document without prior notice.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, UNDER NO CIRCUMSTANCES SHALL NOKIA OR ANY OF ITS LICENSORS BE RESPONSIBLE FOR ANY LOSS OF DATA OR INCOME OR ANY SPECIAL, INCIDENTAL, CONSEQUENTIAL OR INDIRECT DAMAGES HOWSOEVER CAUSED.

THE CONTENTS OF THIS DOCUMENT ARE PROVIDED "AS IS". EXCEPT AS REQUIRED BY APPLICABLE LAW, NO WARRANTIES OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, ARE MADE IN RELATION TO THE ACCURACY, RELIABILITY OR CONTENTS OF THIS DOCUMENT. NOKIA RESERVES THE RIGHT TO REVISE THIS DOCUMENT OR WITHDRAW IT AT ANY TIME WITHOUT PRIOR NOTICE.

The third-party applications provided with your device may have been created and may be owned by persons or entities not affiliated with or related to Nokia. Nokia does not own the copyrights or intellectual property rights to the third-party applications. As such, Nokia does not take any responsibility for end-user support, functionality of the applications, or the information in the applications or these materials. Nokia does not provide any warranty for the third-party applications. BY USING THE APPLICATIONS YOU ACKNOWLEDGE THAT THE APPLICATIONS ARE PROVIDED AS IS WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. YOU FURTHER ACKNOWLEDGE THAT NEITHER NOKIA NOR ITS AFFILIATES MAKE ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO WARRANTIES OF TITLE, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, OR THAT THE APPLICATIONS WILL NOT INFRINGE ANY THIRD-PARTY PATENTS, COPYRIGHTS, TRADEMARKS, OR OTHER RIGHTS.

Your device may have preinstalled bookmarks and links for third-party internet sites. You may also access other third-party sites through your device. Third-party sites are not affiliated with Nokia, and Nokia does not endorse or assume liability for them. If you choose to access such sites, you should take precautions for security or content.

The availability of particular products and applications and services for these products may vary by region. Please check with your Nokia dealer for details, and availability of language options.

Some operations and features are SIM card and/or network dependent, MMS dependent, or dependent on the compatibility of devices and the content formats supported. Some services are subject to a separate charge.

Copyright protections may prevent some images, music (including ringing tones), and other content from being copied, modified, transferred, or forwarded.

Refer to the user guide for other important information about your device.

ISSUE 1 EN

Home Media Server

 **Important:** Always enable one of the available encryption methods to increase the security of your wireless LAN connection. Using encryption reduces the risk of unauthorized access to your data.

Home Media Server uses UPnP architecture to connect to compatible devices through wireless LAN. UPnP architecture uses the security settings of the wireless LAN connection.

With Home Media Server you can easily catalog music, pictures, and video files on your compatible PC. You can create custom music playlists, photo albums, and movie collections. You can transfer compatible media files to your device and back up files from your device to your PC. You can use your device as a remote control, and show media files from the device or PC to a UPnP compatible networked home media player such as a PC, television, or stereo system.

Install Home Media Server on a PC

Install the Home Media Server application to your compatible PC from the CD-ROM supplied with your

device. Home Media Server requires Microsoft Windows 2000 or Windows XP operating system. If you have a firewall to protect your PC, you may need to change settings to allow the PC to work with your mobile device. Follow the on-screen installation instructions.

Manage your media files

To keep track of your songs, digital photos, and video clips, locate the files on your compatible PC and add the files or entire folders to Home Media Server.

You can designate folders where you keep compatible media files on your PC as watch folders. When you place new media files in watch folders, Home Media Server adds them to your library and keeps them updated automatically.

Transfer files from PC to your device

- 1 Using your mobile device, connect to the Home Media Server on your compatible PC.
On your compatible PC, using the Home Media Server application, select your device in the devices menu.

- 2 Select a media file library you want to transfer.
- 3 Select a single media file.
- 4 Select the option to transfer the file to the mobile device.

Transfer files from your device to PC

- 1 Using your mobile device, connect to the Home Media Server on your compatible PC; or on your compatible PC, using the Home Media Server application, select your device in the devices menu.
- 2 Select the file you want to transfer.
- 3 Select the option to transfer the file to the Home Media Server on your compatible PC.

Show files from PC in other devices

You can use your mobile device as a remote control to show compatible media files from Home Media Server on your compatible PC in other UPnP compatible devices of your home network. For example, you can use your mobile device to control playback of compatible music files stored on your PC through your UPnP compatible home audio system using a UPnP compatible multimedia receiver.

Control media files with your mobile device

- 1 Using your mobile device, connect to the Home Media Server on your compatible PC.
- 2 Select the media library containing the file you want to control.
- 3 Select a media file.
- 4 Select the compatible device on which the file is shown.

More information

For more information on Home Media Server, visit www.simplecenter.net/nokia or press **F1** in the Home Media Server application to open Help.