



Impossibly thin, insanely fast, and designed for gaming, the Razer™ Blade 14-inch is the world's thinnest gaming laptop. Built with a 0.66-in. ultra-thin profile and a weight of less than five pounds, the Razer Blade is the thinnest and lightest gaming laptop ever created. With a fourth-generation Intel® Core™ i7 Processor, the latest NVIDIA® GeForce® GTX graphics, and ground-breaking storage performance, the Razer Blade has more power per square inch than any ultra-portable or gaming laptop in its class.

Designed for gaming, the Razer Blade 14-inch gaming laptop is equipped with gaming-grade peripherals built right in. The laptop features Razer Synapse 2.0, a fully programmable, anti-ghosting, backlit keyboard, adjustable ultra-sensitive trackpad, and plenty of green USB 3.0 ports that are ready to plug and play. Do more, game more, anywhere, anytime.

The Razer Blade is the world's thinnest gaming laptop.

## TABLE OF CONTENTS

1. PACKAGE CONTENTS / REGISTRATION / TECHNICAL SUPPORT .....	2
2. BASIC FEATURES.....	3
3. SETTING UP YOUR RAZER BLADE .....	4
4. USING YOUR RAZER BLADE.....	18
5. CONFIGURING YOUR RAZER BLADE.....	21
6. SAFETY AND MAINTENANCE .....	35
7. LEGALESE .....	37

---


## 1. PACKAGE CONTENTS / REGISTRATION / TECHNICAL SUPPORT

### PACKAGE CONTENTS

- Razer Blade
- Power Adapter
- Micro-Fiber Cleaning Cloth
- Quick Start Guide

### REGISTRATION

Please visit [www.razerzone.com/registration](http://www.razerzone.com/registration) for online product registration.



### TECHNICAL SUPPORT


What you'll get:

- 1 year limited manufacturer's warranty.
- 1 year limited battery warranty.
- Access to manual and free online technical support at [www.razersupport.com](http://www.razersupport.com).

For further assistance, contact us:

Country	Phone	Email
Canada / US	1-855-87-25233 (BLADE)	bladesupport@razerzone.com
Singapore	800-6011456	bladesupport_ap@razerzone.com
China	400-0808-767 400-0808-769	support-cn@razerzone.com
International	1-760-448-8997	bladesupport@razerzone.com

## 2. BASIC FEATURES




- A. Webcam Indicator Light
- B. Webcam
- C. Array Microphone
- D. 14" HD+ Display
- E. Power Button
- F. Stereo Speakers Incorporating Dolby® Home Theater® v4 Technology
- G. Backlit Keyboard

- H. Multi-touch Trackpad
- I. Front LED Power Indicator
- J. 3x USB 3.0 Ports
- K. HDMI 1.4a Port
- L. Kensington Security Slot
- M. Power Port
- N. 3.5mm Combo Port


---

### 3. SETTING UP YOUR RAZER BLADE

***Connect the Power Adapter as follows:***




Make sure that the AC plug is properly inserted into the power outlet and the power adapter. An indicator will light up to show that the adapter is receiving appropriate power. Insert the power adapter's connector into the Razer Blade's power port. Press the power button to turn on your Razer Blade.



For first time use, please fully charge your Razer Blade or connect it to a power outlet before turning it on. It takes approximately 3 hours to fully charge the Razer Blade.


## WINDOWS®8 SETUP GUIDE

1. Select the language for your Operating System.  
Choose from the list your preferred default language for Razer Blade.




Click **Next**.

2. Enter your Windows product key in the given field.




Refer to the Microsoft® label under your Razer Blade and key in the necessary information.



Click **Next**.

### 3. Personalize your Windows® 8


Choose your preferred desktop theme and PC name.




Click **Next**.

#### 4. Customize your system settings.

The Setup Wizard includes a set of pre-configured settings that you can use to quickly set up your Windows device. Click **Use express settings** to use the list of settings shown on the interface and skip to step 7 of this guide.




Alternatively, you can click Customize to manually configure your Region, Language and Keyboard Layout.



Click **Next**.

5. Setup a login account.

Enter your **User name** for logging into Windows. If you wish to secure your login with a password, fill out the **Password**, **Reenter password** and **Password hint** textboxes.



← Sign in to your PC

If you want a password, choose something that will be easy for you to remember but hard for others to guess.

User name john.doe X

Password

Reenter password

Password hint

Finish

Click **Finish** to complete the Windows setup.

## CONNECTING TO THE INTERNET


1. Activate the Charm bar by moving the cursor to the right side of the screen.




2. Click the Settings icon on the Charm bar.




3. Click the wireless network icon.




4. Click the network you wish to connect to and click **Connect**.



5. Enter the network password (if any) and click **Next**.




6. Select whether to turn network sharing on/off.



7. Once you are connected to the wireless network, click anywhere outside the sidebar to return to the desktop.

## RAZER SYNAPSE 2.0 ACCOUNT CREATION & INSTALLATION

Razer Synapse 2.0 allows you to sync your Razer Blade and other supported Razer peripherals to a cloud server to download driver and firmware updates. You will also be able to configure the key bindings, profiles, macros, backlighting and more within the application. All your custom settings will be stored in the cloud too.



1. Razer Synapse 2.0 will start automatically once you enter Windows 8.
2. Register for a Razer Synapse 2.0 account and confirm your new account.
3. Open Razer Synapse 2.0 and login to your account.
4. Wait until Synapse 2.0 automatically downloads and installs the necessary drivers.


















## 4. USING YOUR RAZER BLADE

### STATUS INDICATORS







	Sleep	On	Low Battery (15 min left)	Low Battery (3 min left)
Front LED Indicator				



### KEYBOARD FUNCTION KEYS





Function Keys	To activate the features below, press the 'Fn' key and the respective key.
  	The audio volume controls allow you to mute (  ), decrease (  ) and increase (  ) the audio output.
	Toggles the monitor output.
  	The media keys allow you to play/pause (  ) a track or skip tracks backward (  ) and forward (  ).
 	The screen brightness keys allow you to customize the brightness of the screen.
 	The key backlight can be customized to your preference.

## TRACKPAD GESTURES

<p>Right Edge Swipe</p>  <p>Activate Charms Bar</p>	<p>Top Edge Swipe</p>  <p>Display app commands</p>
<p>Left Edge Swipe</p>  <p>Open previously used app</p>	<p>2 Finger Vertical Scroll</p>  <p>Scroll up / down</p>
<p>2 Finger Horizontal Scroll</p>  <p>Scroll left / right</p>	<p>2 Finger Rotate</p>  <p>Change orientation when viewing desktop images and other files</p>

2 Finger Pinch	2 Finger Expand
 <p data-bbox="386 562 537 594">Zoom out</p>	 <p data-bbox="979 604 1105 636">Zoom in</p>

3 Finger Horizontal Swipe	3 Finger Vertical Swipe
 <p data-bbox="201 1079 721 1203">Move forward / backward when viewing desktop images and other files</p>	 <p data-bbox="792 1131 1295 1215">Play (Pause) / Stop when viewing desktop images and other files</p>


---

## 5. CONFIGURING YOUR RAZER BLADE

*Disclaimer: The features listed here require you to log in to Razer Synapse 2.0. These features are also subject to change based on the current software version and your Operating System.*


### **KEYBOARD TAB**




The Keyboard Tab is your default tab when you first install Razer Synapse 2.0. This tab allows you to customize your device's profiles and key assignments.



## Profile


A profile is a convenient way of organizing all your custom settings and you can have an infinite number of profiles at your disposal. Any changes made within each tab are automatically saved to the current profile and stored into the cloud servers.



You can create a new profile by clicking the  button or delete the current profile by clicking the  button. The  button allows you to Copy, Import, and Export profiles. Your current profile by default is named "Profile" however; you can rename it by typing on the text field below *PROFILE NAME*. Each profile can be set to automatically activate when you run a program or application through the use of the *LINK PROGRAM* option. Alternatively, each profile can be set to *FN + 0 - 9* using the *SHORTCUT* dropdown box for fast profile switching.


## Customize Tab

The Customize Tab is where you can modify the basic functionalities of your device such as key assignments and trackpad sensitivity to suit your gaming needs. The changes made in this tab are automatically saved to your current profile.



## Key Assignment Menu

Initially, each key is set to *DEFAULT*. However, you may change the function of this key by clicking the desired key to access the Key Assignment Menu.



Listed below are the customization options and their description.



### Default

This option enables you to return the key to its original function. To choose the *DEFAULT*, simply select it from the Key Assignment Menu.



### Keyboard Function

This option enables you to change any key into another keyboard function. To choose a keyboard function, select *KEYBOARD FUNCTION* from the Key Assignment Menu and enter the key you wish to use on the given field below. You may also include modifier keys such as *Ctrl*, *Shift*, *Alt* or any of those combinations.



## Mouse Function

This option allows you to change any key into a mouse button function. To choose a mouse function, select *MOUSE FUNCTION* from the Key Assignment Menu and an *ASSIGN BUTTON* submenu will appear.

Listed below are the functions which you can choose from the Assign Button submenu:

- Left Click - Performs a left mouse click using the assigned button.
- Right Click - Performs a right mouse click using the assigned button.
- Scroll Click - Activates the universal scrolling function.
- Double Click - Performs a double left click using the assigned button.
- Mouse Button 4 - Performs a “Backward” command for most internet browsers.
- Mouse Button 5 - Performs a “Forward” command for most internet browsers.
- Scroll Up - Performs a “Scroll Up” command using the assigned button.
- Scroll Down - Performs a “Scroll Down” command using the assigned button.



## Inter-device

Inter-device allows you to change the functionality of other Razer Synapse 2.0-enabled devices. Some of these functionalities are device-specific such as using your Razer gaming keyboard to change the Sensitivity Stage of your Razer gaming mouse. When you select Inter-device from the Key Assignment Menu, a sub-menu will appear.

*DEVICE TO LINK* allows you to choose which currently connected Razer device can be linked while *FUNCTION* allows you to choose which functionality you want to use for the linked device.



## Macro

A Macro is a prerecorded sequence of keystrokes and button presses that is executed with precise timing. By setting a key to Macro, you can conveniently execute a chain of commands. When you select this option from the Key Assignment Menu, a submenu will appear which allows you to choose a prerecorded macro command. See the **Macros Tab** to learn more about creating Macro commands.



### Switch Profile

The Switch Profile enables you to change profiles on the fly and immediately load all your pre-configured settings. When you select Switch Profile from the Key Assignment Menu, a sub-menu will appear that will allow you to choose which profile to use. An on-screen display will automatically appear whenever you switch profiles.



### Launch Program

Launch Program allows you to launch a program or a website using the assigned key. When you select Launch Program from the Key Assignment Menu, two options will appear which allow you to search for the specific program you want to open or write the address of the website you want to visit.



### Multimedia Function

This option allows you to bind multimedia playback controls to your device. After selecting Multimedia Function, a submenu will appear. Listed below are the multimedia playback controls you can choose from the submenu:

Volume Down	- Decreases the audio output.
Volume Up	- Increases the audio output.
Mute Volume	- Mutes the audio.
Mic Volume Up	- Increases the microphone volume.
Mic Volume Down	- Decreases the microphone volume.
Mute Mic	- Mutes the microphone.
Mute All	- Mute both microphone and audio output.
Play / Pause	- Play, pause, or resume playback of the current media.
Previous Track	- Play the previous track.
Next Track	- Play the next track.




### Disable

This option renders the assigned key unusable. Use Disable if you do not want to use the key or if it interferes with your gaming.

## Trackpad Configuration

You can adjust the response of the trackpad by clicking the image of the trackpad on the user interface.



Listed below are the options and their descriptions.

### Sensitivity


Sensitivity pertains to how much effort is needed to move the cursor in any direction. The higher the sensitivity, the more responsive the track-panel will be.

### Acceleration

Acceleration increases the cursor's movement speed depending on how quickly you move your finger on the track-panel. The higher the value, the faster the cursor accelerates.


## Lighting Tab

This tab allows you to adjust the intensity of the keyboard's backlight by using the *BRIGHTNESS* slider.




## Gaming Mode Tab




The Gaming Mode Tab helps you prevent accidental key presses. Depending on your settings, you may choose to disable the Windows key, Alt + Tab and Alt + F4. Furthermore, you can maximize the effect of Anti-Ghosting by activating the Gaming mode function.





## MACROS TAB

The Macros Tab allows you to create a series of precise keystrokes and button presses. This tab also allows you to have numerous macros and extremely long macro commands at your disposal.



The Macro section works similarly to Profile wherein you can rename a macro by typing on the field below *MACRO NAME*. There are also other options available in the macro section such as creating a new macro by clicking the  button and deleting the current macro by clicking the  button. The  button allows you to Copy, Import, and Export macros.


To create a macro command, simply click the  button and all your keystrokes and button presses will automatically register on the macro screen. When you are done recording your macro commands, click on the  button to end the session.





The Macro section allows you to input the delay in-between commands. In **Record Delay** the delay in-between commands are registered as how it is entered. The **Default Delay** uses a predefined time (expressed in seconds) as the delay. And **No Delay** omits all the pauses in-between keystrokes and button presses.




*Note: You may use up to three decimal places when inserting values on the seconds (sec) field.*

Once you have recorded a macro, you may edit the commands you have entered by selecting each command on the macro screen. Each keystroke or button press is arranged sequentially with the first command shown at the top of the screen.





The  button allows you to edit a particular command and the  button enables you to delete a command. The  and  buttons gives you the option to move the command up or down.


The  button allows you to put in additional keystrokes, button presses or time delays either before or after the selected command.

Once you have pressed the **INSERT** button, a new display window will appear beside the list of macro commands. The dropdown menu on this window allows you to choose a keystroke or a delay to be added in before or after the highlighted macro command.





You may add in a new set of macro commands by clicking the  button on the keystroke menu; or input time delays on the duration field using the delay menu.



---

## 6. SAFETY AND MAINTENANCE

### ***SAFETY GUIDELINES***

In order to achieve maximum safety while using your Razer Blade, we suggest that you adopt the following guidelines:

1. Should you have trouble operating the device properly and troubleshooting does not work, unplug the device and contact the Razer hotline or go to [www.razersupport.com](http://www.razersupport.com) for support. Do not attempt to service or fix the device yourself at any time.
3. Do not take apart the device (doing so will void your warranty) and do not attempt to operate it under abnormal current loads.
4. Keep the device away from liquid, humidity or moisture. Operate the device only within the specific temperature range of 0°C (32°F) to 40°C (104°F). Should the temperature exceed this range, unplug and switch off the device in order to let the temperature stabilize to an optimal level.

### ***COMFORT***

Research has shown that long periods of repetitive motion, improper positioning of your computer peripherals, incorrect body position, and poor habits may be associated with physical discomfort and injury to nerves, tendons, and muscles. Below are some guidelines to avoid injury and ensure optimum comfort while using your Razer Blade.

1. Position your laptop directly in front of you. If you have an external mouse, position it next to the laptop. Place your elbows next to your side, not too far away and your mouse within easy reach.
2. Adjust the height of your chair and table so that the laptop is at or below elbow height.
3. Keep your feet well supported, posture straight and your shoulders relaxed.

4. During gameplay, relax your wrist and keep it straight. If you do the same tasks with your hands repeatedly, try not to bend, extend or twist your hands for long periods.
5. Do not rest your wrists on hard surfaces for long periods. When using an external mouse, use a wrist rest to support your wrist while gaming.
6. Do not sit in the same position all day. Get up, step away from your desk and do exercises to stretch your arms, shoulders, neck and legs.
7. If you should experience any physical discomfort while using your laptop, such as pain, numbness, or tingling in your hands, wrists, elbows, shoulders, neck or back, please consult a qualified medical doctor immediately.

### **BATTERY**

The Razer Blade contains an internal, lithium-ion polymer rechargeable battery. In general, the life expectancy of such batteries is dependent upon usage. Heavy daily usage will result in shorter battery life. Casual use will extend battery life. If you suspect that the lithium-ion rechargeable battery inside the Razer Blade may be drained (has a low charge), try charging it. If the battery does not recharge after several attempts, it may be non-operational. Dispose of batteries according to your local environmental laws and guidelines.

---

## 7. LEGALESE

### ***COPYRIGHT AND INTELLECTUAL PROPERTY INFORMATION***

© 2013 Razer Inc. All rights reserved. Razer, For Gamers By Gamers, and the triple-headed snake logo are trademarks or registered trademarks of Razer Inc. and/or affiliated companies in the United States or other countries. All other trademarks are the property of their respective owners. Actual product may differ from pictures. Information is correct at time of printing. Windows and the Windows logo are trademarks of the Microsoft group of companies.

Manufactured under license from Dolby Laboratories.

Dolby, Dolby Home Theater and the double-D symbol are trademarks of Dolby Laboratories.

Razer Inc. (“Razer”) may have copyright, trademarks, trade secrets, patents, patent applications, or other intellectual property rights (whether registered or unregistered) concerning the product in this Master Guide. Furnishing of this Master Guide does not give you a license to any such copyright, trademark, patent or other intellectual property right. The Razer Blade (the “Product”) may differ from pictures whether on packaging or otherwise. Razer assumes no responsibility for such differences or for any errors that may appear. Information contained herein is subject to change without notice.

### ***LIMITED PRODUCT WARRANTY***

For the latest and current terms of the Limited Product Warranty, please visit [www.razerzone.com/warranty](http://www.razerzone.com/warranty).

### ***LIMITATION OF LIABILITY***

Razer shall in no event be liable for any lost profits, loss of information or data, special, incidental, indirect, punitive or consequential or incidental damages, arising in any way out of distribution of, sale of, resale of, use of, or inability to use the Product. In no event shall Razer’s liability exceed the retail purchase price of the Product.

### ***COSTS OF PROCUREMENT***

For the avoidance of doubt, in no event will Razer be liable for any costs of procurement unless it has been advised of the possibility of such damages, and in no case shall Razer be liable for any costs of procurement liability exceeding the retail purchase price of the Product.

### ***GENERAL***

These terms shall be governed by and construed under the laws of the jurisdiction in which the Product was purchased. If any term herein is held to be invalid or unenforceable, then such term (in so far as it is invalid or unenforceable) shall be given no effect and deemed to be excluded without invalidating any of the remaining terms. Razer reserves the right to amend any term at any time without notice.

### ***FCC DECLARATION OF CONFORMANCE***

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

For more information, refer to the online help system on [www.razerzone.com](http://www.razerzone.com).

### ***FCC CAUTION STATEMENT***

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

**IMPORTANT NOTE:**

**FCC Radiation Exposure Statement:**

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.

***USAGE RESTRICTIONS***

This Razer device was developed and designed to comply with the various wireless and telecom agency requirements throughout the world. This ensures that the device do not cause any harm to Public Switching Telecommunication Networks (PSTN) and do not violate any power and frequency spectrum allocations on a country by country basis. This device was also designed to be compliant with regulatory agency limits for Electromagnetic Compatibility (EMC).

***IMPORTANT NOTICE FOR USE IN HEALTHCARE ENVIRONMENTS***

This Razer device is not a medical device and is not listed under UL or IEC 60601 (or equivalent). This device should be kept at a certain distance to avoid harmful effects to patients or medical equipment.

***AVIATION USAGE RESTRICTIONS***

Certain restrictions apply to this device while on-board an aircraft. Razer encourages you to understand these restrictions to ensure the flight's safety and security.