

2-Port Parallel PCI Card

User Manual

Ver. 1.00

**All brand names and trademarks are properties of their
Respective owners.**

Features and Benefits

- Features
- Compliant with PCI Local Bus Specification, Revision 2.3
 - Add two IEEE 1284 Parallel Ports on system
 - Easy Plug and Play
 - Automatically selects IRQ & I/O address
 - Supports Standard Parallel Port (SPP), Enhanced Parallel (EPP) & Enhanced Capability Port (ECP)
 - Faster data rates up to 1.5Mbytes/sec
- Bus
- PCI 32-bit
- Connectors
- 2 x DB25 female parallel connectors

System Requirements

- Windows® 2000, XP/2003 32/64 bit, Vista 32/64 bit
- Available PCI slot

Package Contents

- 1 x 2-Port Parallel PCI Card

- 1 x Driver CD
- 1 x User's Manual

Hardware Installation

1. Turn Off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCI slot.
4. To install the card, carefully align the card's bus connector with the selected PCI slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Replace the computer cover and reconnect the power cord.

Driver Installation

For Windows® 2000/XP/Server 2003

1. Don't insert the PCI card into PCI slot.
2. At the Windows desktop click **Start**, then **Run**.
3. Type **D:\PCI_IO\MCS9865\XP\PciSetup.exe**, then click **OK**.
4. Press "**Install**" button to install the drivers.
5. Click "**Exit**" button to complete the driver installation.

6. Shutdown the PC.
7. Place the PCI card into PCI slot and then power on the system.
8. Once the system gets booted the Windows will automatically start installing the device driver software.

For Windows® XP-x64/Server 2003-x64

1. Don't insert the PCI card into PCI slot.
2. Type **D:\PCI_IO\MCS9865\XP64\PCISetup.exe**, then click **OK**.
3. Press "**Install**" button to install the drivers.
4. Click "**Exit**" button to complete the driver installation.
5. Shutdown the PC.
6. Place the PCI card into the PCI slot then power on the system.
7. Once the system gets booted the Windows will automatically start installing the device driver software.

For Windows® Vista

1. Don't insert the PCI card into PCI slot.
2. Type **D:\PCI_IO\MCS9865\Vista32\PciSetup.exe**, then click **OK**.
3. Press "**Install**" button to install the drivers.

4. Click “**Exit**” button to complete the driver installation.
5. Shutdown the PC.
6. Place the PCI card into PCI slot and then power on the system.
7. Once the system gets booted the Windows will automatically start installing the device driver software.

For Windows® Vista-x64

1. Don't insert the PCI card into PCI slot.
2. Type **D:\PCI_IO\MCS9865\Vista64\PCISetup.exe**, then click **OK**.
3. Press “**Install**” button to install the drivers.
4. Click “**Exit**” button to complete the driver installation.
5. Shutdown the PC.
6. Place the PCI card into PCI slot and then power on the system.
7. Once the system gets booted the Windows will automatically start installing the device driver software.

To Verify Windows® Driver Installation

Click on the **Device Manager** tab in System Properties, which you access from the Windows Control Panel. You should see two **PCI ECP Parallel Port ...** installed under **Ports (COM & LPT)** item.