

# Ultrasonic Diffuse, Dual Transistor Outputs Type M18 and M30

CARLO GAVAZZI



- M18 and M30 PBT housing
- Sensing distance: 60 - 3500 mm
- Remote Teach by wire
- Outputs: 2 multi function switching outputs PNP, NPN, NO or NC
- Setup of "Normal Switching", "Window" or "Adjustable Hysteresis" function
- Power supply: 12 to 30 VDC
- 8° beam angle
- Protection: Short-circuit, reverse polarity, transients
- Protection degree IP 67
- Cable or M12 plug, 5 pin

## Product Description

A self-contained multi function diffuse ultrasonic sensor with a sensing range of 60 to 3500 mm. 2 switching outputs - easily set up for 3 different switching modes and adjusted by teach-in - makes it ideal for level control tasks in a wide variety of vessels. A sturdy one-piece polyester housing provides

the perfect packaging for the sophisticated micro-processor controlled and digitally filtered sensor electronics. Excellent EMC performance and precision are typical features of this sensor based on true distance measurement.

## Ordering Key

**UA18CLD20PPM1TR**

Ultrasonic sensor	_____
Housing style	_____
Housing size	_____
Housing material	_____
Housing length	_____
Detection principle	_____
Sensing distance	_____
Output type	_____
Output configuration	_____
Connection	_____
Remote teach	_____

## Type Selection

Housing dimensions	Connection	Rated operating dist. (S <sub>n</sub> )	Outputs	Ordering no.
M18 x 93 mm	Plug M12, 5 pin	60-500 mm	2 x PNP, NO/NC	UA18CLD05PPM1TR
M18 x 93 mm	Cable	60-500 mm	2 x PNP, NO/NC	UA18CLD05PPTR
M18 x 93 mm	Plug M12, 5 pin	60-500 mm	2 x NPN, NO/NC	UA18CLD05NPM1TR
M18 x 93 mm	Cable	60-500 mm	2 x NPN, NO/NC	UA18CLD05NPTR
M18 x 93 mm	Plug M12, 5 pin	100-800 mm	2 x PNP, NO/NC	UA18CLD08PPM1TR
M18 x 93 mm	Cable	100-800 mm	2 x PNP, NO/NC	UA18CLD08PPTR
M18 x 93 mm	Plug M12, 5 pin	100-800 mm	2 x NPN, NO/NC	UA18CLD08NPM1TR
M18 x 93 mm	Cable	100-800 mm	2 x NPN, NO/NC	UA18CLD08NPTR
M18 x 93 mm	Plug M12, 5 pin	200-2000 mm	2 x PNP, NO/NC	UA18CLD20PPM1TR
M18 x 93 mm	Cable	200-2000 mm	2 x PNP, NO/NC	UA18CLD20PPTR
M18 x 93 mm	Plug M12, 5 pin	200-2000 mm	2 x NPN, NO/NC	UA18CLD20NPM1TR
M18 x 93 mm	Cable	200-2000 mm	2 x NPN, NO/NC	UA18CLD20NPTR
M30 x 125 mm	Plug M12, 5 pin	300-3500 mm	2 x PNP, NO/NC	UA30CLD35PPM1TR
M30 x 123.5 mm	Cable	300-3500 mm	2 x PNP, NO/NC	UA30CLD35PPTR
M30 x 125 mm	Plug M12, 5 pin	300-3500 mm	2 x NPN, NO/NC	UA30CLD35NPM1TR
M30 x 123.5 mm	Cable	300-3500 mm	2 x NPN, NO/NC	UA30CLD35NPTR

## Technical Data

Rated operational volt. (U <sub>e</sub> )	12 to 30 VDC (ripple included)	UA18..D35	60 ms
Ripple	10%	Voltage drop (U <sub>d</sub> )	< 1 V
Output current (I <sub>e</sub> )	max. 500 mA (continuous)	Off-state current (I <sub>r</sub> )	< 10 µA
No-load supply current (I <sub>o</sub> )	≤ 35 mA	Teach-in Set point adjustment	NO/NC selection Switching modes selection
Protection	Short-circuit, transients and reverse polarity	Indication	Set points, 2 LEDs yellow Echo, 1 LED green
Rated insulation voltage	> 1 kV	Rated operating distance	60 - 3500 mm
Output	2 PNP open collector outputs, NO or NC	Operating Frequency	
Power-on delay		CLD05 + CLD08	10 Hz
UA18..D05/D08	60 ms	CLD20	5 Hz
UA18..D20	90 ms	CLD35	2.5 Hz




Technical Data Ccont.)

Carrier Frequency	CLD05	330 kHz	Ambient temperature Operating and Storage	-15° to +70°C (5° to +158°F)	
	CLD08	300 kHz			
	CLD20	180 kHz			
	CLD35	130 kHz			
Response time			Degree of protection	IP 67 (Nema 1, 3, 4, 6, 13)	
			Housing material	PBT	
	CLD05	20 ms	Tightening torque	M18 M30	2.6 Nm 7.5 Nm
	CLD08	20 ms			
	CLD20	40 ms			
CLD35	80 ms				
			Connection	2 m, 5 x 0.25 mm²	
Hysteresis (H) (differential travel)			Plug	M12, 5-pin	
			Cables for plug (M1)	CONM15 series	
			Weight	UA 18 ...A.	96 g
				UA 18 ...A.M1	57 g
				UA 30 ...A.	199 g
		UA 30 ...A.M1		140 g	
Repeatability			CE-marking	Yes	
	CLD05 + CLD08	0.2% / 0.5 mm			
	CLD20	0.1%			
	CLD35	0.2% / 1.2 mm			
Temperature compensation	Yes				
Beam angle	8°				

Switching Operation

Normal Switching Operation




The following 3 different modes of the switching outputs can be selected:

I Normal switching function


II Window function

III Adjustable hysteresis


All these functions may be programmed/taught by means of the Teach-in input (pin 5) present in the connector. Each mode has a unique indication using the Echo, P1 and P2 LEDs. The programming/Teach-In procedure is shown in the following flow diagram:




Windows Function



Hysteresis Adjustment



Echo P1 P2  
Green Yellow Yellow




Normal function:


The Echo LED is ON when an echo is received (alignment LED). P1 and P2 LEDs are indicating status of the switching outputs.

## Dimensions


### M18 cable




### M18 plug



### M30 cable




### M30 plug




## Detection Range


### UA18CLD05




### UA18CLD08





### UA18CLD20



### UA30CLD35



## Wiring Diagram



## Teach-in procedure

### Normal switching function

#### The Teach-In function

When - in the following paragraphs, the term "Activate Teach-In" is used, this means: make contact between the Teach-in wire and GND wire once (ON-OFF) - could be done with an externally mounted switch.

When - in the following paragraphs, the term "Hold Teach-In" is used, this means: make contact between the Teach-in wire and GND wire (ON) - could be done with an externally mounted switch.

#### Teach-In of P1 (SP1 position)

Hold Teach-In for 8 seconds until P1 and Echo LED's start flashing 2 times per second.

The sensor is now in teach mode for P1:

P1 LED will now flash once per second and the Echo LED returns to normal function (alignment LED).

The Teach-In function is now open for 1 minute to do the programming of P1.

Place the target at the new position P1.

Activate Teach-in: P1 is now programmed.

Sensor returns to normal function with new value for P1.

**Switching output characteristics** can be selected during teaching of the set point P1. If activating the Teach-In as the LED is ON - the switching output will have NO characteristics, if doing this as the LED is OFF, the switching output will have NC characteristics.

#### Teach-In of P2 (SP2 position)

Hold Teach-In for 14 seconds until the P2 and Echo LEDs start flashing 2 times per second. After 8 seconds, the P1 and Echo LEDs will start flashing, but this must be ignored and after an additional 5 seconds the P2 is reached.

The sensor is now in teach mode for P2:

P2 LED is flashing once per second. The Echo LED returns to normal function (alignment LED).

Teach-mode is now open for 1 minute to do the programming of P2.

Move the target to the new position P2.

Activate Teach-in: P2 is now programmed.

Sensor returns to normal function with new value for P2.

**Switching output characteristics** can be selected during teaching of the set point P2. If activating the Teach-In as the LED is ON - the switching output will have NO characteristics, if doing this as the LED is OFF, the switching output will have NC characteristics.

### Window function/ Hysteresis adjustment

Hold Teach-In for 20 seconds - to skip through the P1 and P2 teaching sequences - until P1, P2 and Echo LED's start flashing 2 times per second indicating the function teach mode.

De-activate Teach-In to enter teach mode for Window Function / Hysteresis Adjustment:

P1 and P2 LED are flashing once per second.

The Echo LED returns to normal function (alignment LED).

Teach-mode is now open for 1 minute to complete the programming.

Now activate Teach-In at the desired LED indication (see below):






#### P1 and P2 LED are OFF = Window Function

Activating Teach-In now, makes the sensor operate in Windows Function mode. If there is an object between P1 and P2, SP1 will switch ON and SP2 will switch OFF. If there is no object between P1 and P2, SP1 will switch OFF and SP2 will switch ON.

#### P1 and P2 LED are ON = Hysteresis Adjustment

Activating Teach-In now, makes the sensor operate in Hysteresis Adjustment mode. (The switching output SP1 will be NO at P1 with hysteresis P1-P2 and switching output SP2 will be NC also at P1 with hysteresis P1-P2).

## Installation Hints

<p><i>To avoid interference from inductive voltage/current peaks, separate the prox. switch power cables from any other power cables, e.g. motor, contactor or solenoid cables</i></p> 	<p><i>Relief of cable strain</i></p> <p>Incorrect</p>  <p>Correct</p>  <p>The cable should not be pulled</p>	<p><i>Protection of the sensing face</i></p>  <p>A proximity switch should not serve as mechanical stop</p>	<p><i>Switch mounted on mobile carrier</i></p>  <p>Any repetitive flexing of the cable should be avoided</p>
--	--	---	---