

Industrial Ethernet Connectors xs5/xs6

Support for Ethernet/IP, Ether-CAT, and Other Popular Networks Based on Ethernet

- A lineup of Tough RJ45 Connectors for use outside of panels and Environment-resistance Connectors with IP67 protection (M12).
- RJ45 Assembly Connectors are available for easy wiring onsite.
- SmartClick Connectors are used on Environment-resistance Connectors (M12) and provide compatibility with traditional screw connectors for one-touch (1/8 turn) connection.
- AWG22 cables that are suitable for wiring outside of panels are used for all models.
- More variations with the addition of Cables with Right-angle Connectors and Straight Terminals for PCBs.



Ordering Information

Appearance	Туре	Cable length (m)	Model
, pp. and	77-	0.5	XS5H-T421-BM0-K
		1	XS5H-T421-CM0-K
		2	XS5H-T421-DM0-K
	Cable with Connector on One End	3	XS5H-T421-EM0-K
	(M12 straight)	5	XS5H-T421-GM0-K
93		10	XS5H-T421-JM0-K
		15	XS5H-T421-KM0-K
		0.5	XS5W-T421-BM2-K
		1	XS5W-T421-CM2-K
		2	XS5W-T421-DM2-K
	Cable with Connectors on Both Ends (M12 straight/M12 straight)	3	XS5W-T421-EM2-K
	(WITZ StraightviviTZ Straight)	5	XS5W-T421-GM2-K
		10	XS5W-T421-JM2-K
		15	XS5W-T421-KM2-K
		0.3	XS5W-T421-AMC-K
		0.5	XS5W-T421-BMC-K
		1	XS5W-T421-CMC-K
	Cable with Connectors on Both Ends (M12 straight/RJ45)	2	XS5W-T421-DMC-K
		3	XS5W-T421-EMC-K
		5	XS5W-T421-GMC-K
		10	XS5W-T421-JMC-K
		15	XS5W-T421-KMC-K
		0.5	XS5H-T422-BM0-K
		1	XS5H-T422-CM0-K
	Oakla with Oarraantan ar Oan Fad	2	XS5H-T422-DM0-K
	Cable with Connector on One End (M12 right-angle)	3	XS5H-T422-EM0-K
8		5	XS5H-T422-GM0-K
Available soon.		10	XS5H-T422-JM0-K
Available 50011.		15	XS5H-T422-KM0-K
		0.5	XS5W-T422-BM2-K
To a second		1	XS5W-T422-CM2-K
	Cable with Connectors on Both Finds	2	XS5W-T422-DM2-K
	Cable with Connectors on Both Ends (M12 right-angle/M12 right-angle)	3	XS5W-T422-EM2-K
a O		5	XS5W-T422-GM2-K
		10	XS5W-T422-JM2-K
Available soon.		15	XS5W-T422-KM2-K



Appearance	Туре		Cable length (m)	Model
			0.3	XS5W-T422-AMC-K
			0.5	XS5W-T422-BMC-K
			1	XS5W-T422-CMC-K
	Cable with Connectors	s on Both Ends	2	XS5W-T422-DMC-K
	(M12 right-angle/RJ45)		3	XS5W-T422-EMC-K
• •			5	XS5W-T422-GMC-K
Available soon.			10	XS5W-T422-JMC-K
			15	XS5W-T422-KMC-K
			0.3	XS5W-T421-AMD-K
			0.5	XS5W-T421-BMD-K
			1	XS5W-T421-CMD-K
	Cable with Connectors on Both Ends		2	XS5W-T421-DMD-K
	(RJ45/RJ4	45)	3	XS5W-T421-EMD-K
			5	XS5W-T421-GMD-K
			10	XS5W-T421-JMD-K
			15	XS5W-T421-KMD-K
	RJ45 Assembly Connector			XS6G-T421-1
	M12 Connector for Panel Mounting	Rear locking	0.5	XS5P-T426-5
		Front locking	0.5	XS5P-T427-5
NEW NEW	M12 Panel-mounting PCB Straight Terminals			XS5P-T426-1

2 OMRON

Specifications

Туре	Cable with Con- nector on One End (M12)	Cable with Connectors on Both Ends (M12/M12)	Cable with Connectors on Both Ends (M12/RJ45)	Cable with Connectors on Both Ends (RJ45/RJ45)	RJ45 Assembly Connector	M12 Connector for Panel Mount- ing	M12 Panel- mounting PCB Straight Termi- nals
Item Model	XS5H -T42□-□M0-K	XS5W -T42□-□M2-K	XS5W -T42□-□MC-K	XS5W -T421-□MD-K	XS6G -T421-1	XS5P-T42□-5	XS5P -T426-1
Rated current	3 A 2.5 A 3 A					3 A	4 A
Rated voltage 30 V					125 VDC		
Contact resistance	tact resistance $40 \text{ m}\Omega$ max.					40 mΩ max.	
Insulation resistance	1,000 MΩ min. 1,000 MΩ min. 1,000 MΩ min.					1,000 MΩ min.	
Withstand voltage 1,000 VAC for 60 s (leak current: 1 mA max.)					1,500 VAC for 60 s (leakage current: 1 mA max.)		
Ambient operating temperature	-40 to 70°C -25 to 70°C -25 to 70°C					−25 to 70°C	
Ambient storage temperature	-25 to 70°C -25 to 70°C -25 to 70°C					−25 to 70°C	
Protective struc- ture	I M12: IEC IP67 R.I45: IEC IP20					IEC IP67	

■ Materials and Finish

● Connectors

Model	M12			RJ45	
Item	XS5H and XS5W	XS5P-T42□-5	XS5P-T426-1	XS5W and XS6G	
Contact blocks	PBT resin (UL94V-0)/light gray	PBT resin (UL94V-0)/light gray	PA resin (UL94V-0)/black	PA resin (UL94V-0)/black	
Contacts	Phosphor bronze/nickel base, gold plated (0.4 μm)	Phosphor bronze/nickel base, gold plated (0.4 μm)	Bronze/nickel base, gold plated (0.4 μm)	Phosphor bronze/nickel base, gold plated (1.4 μm)	
Anchors	Zinc diecast/nickel plating	Zinc diecast/nickel plating	Zinc diecast/nickel plating (5 µm)		
Anchors (tabs)	SUS				
Cover	Soft PBT (UL94 V-0)				
Sealing resin		Epoxy resin			
O-rings	Rubber	Rubber	Rubber		
Grounding fixture			Phosphor bronze/nickel base, tin plated (2.0 μm)		
Anchor cover			SUS		
Nuts		Bronze/nickel plated (1.5 μm)	Bronze/nickel plated (1.5 μm)		


Cables

Specifications	UL CM PVC (double shielding) Cat. 5E		
Cores and colors	AWG22 (0.26/7): Yellow, orange, white, and blue		
Outer diameter	6.5 mm		
Sheath color	Light blue		


Note: Connectors with cables only. (XS5H and XS5W)

3


■ Dimensions (Unit: mm)



● Cable with Connectors on Both Ends (M12 Straight/M12 Straight) XS5W-T421-□M2-K




● Cable with Connectors on Both Ends (M12 Straight/RJ45)




4 OMRON

Cable with Connector on One End (M12 Right-angle) Wiring XS5H-T422-□M0-K 1 Yellow Available soon. 2 White 3 Orange 4 Blue L (cable length) 32.3 32.3 44 Blue


● Cable with Connectors on Both Ends (M12 Right-angle/M12 Right-angle)




● Cable with Connectors on Both Ends (M12 Right-angle/RJ45)



● Cable with Connectors on Both Ends (RJ45/RJ45)








Assembly Connector (RJ45) XS6G-T421-1









Applicable wires

6.1 to 6.9 dia.

Stranded wires: AWG22 to AWG24 Solid wires: AWG22 to AWG23


Wiring


● M12 Connector for Panel mounting

XS5P-T42□-5

XS5P-T426-5 (Rear Locking)








XS5P-T427-5 (Front Locking)






Panel Cutout Dimension

Color Yellow

White

Blue




Note 1: The panel cutout dimension is the same for Front-locking and Rearlocking Connectors.


Note 2: Rotational positioning is not possible for connector rotation.


Panel-mounting PCB Straight Terminals (M12)

XS5P-T426-1












Mounting Hole Dimensions

(D Cut Structure)




Mounting Hole Dimensions



Cross-section Diagram C-C

Panel Processing Dimensions



Assembly Procedure

RJ45 Assembly Connectors XS6G-T421-1

- 1. Pass the cable through the cable clamp and the connector housing
- Strip the cable sheath and ground braiding to the correct lengths.

-13 mm**>**

- Follow the color codes and prepare to insert the wires into the splice piece.
- Insert the wires into the splice piece for the length of the splice piece.
- Place the splice piece into the RJ45 data module and engage it.
- Place the data module and the splice piece on the IDC assembly housing.
- 7. Press the data module and the IDC assembly housing together and use pliers or a similar device to make the insulation displacement contact.
- Remove the data module from the IDC assembly housing.
- Place the upper screen plate on the data module and press it over the ground braiding of the cable.
- 10. Place the lower screen plate on the bottom of the data module, align it with the upper screen place, and latch it until you hear it click into place.
- 11. Slide the housing that you placed around the cable in step 1 up to the data module and latch it until you hear it click into place.

12. Tighten the cable clamp. **Pin Assignments**

Pin Assignments for Fast Ethernet 10/100 Mbps

Function/Signal	Industrial Ethernet	EIA/TIA 568A	EIA/TIA 568B	Pin No.	
Transmission Data+/TD+	YE	WH/GN	WH/OG	1	
Transmission Data-/TD-	OG	GN	OG	2	
Receiver Data/RD+	WH	WH/OG	WH	3	
Receiver Data/RD-	BU	OG	GN	6	



M12 Panel-mounting PCB Straight Terminals XS5P-T426-1


Confirming the Number of Parts

The following four parts are included in the package when it is delivered.




Assembly Procedure


- 1. Mount the connector to the PCB.
- 2. Attach the anchor to the panel with the nut.




- 3. Attach the connector that you mounted to the PCB to the panel.
 - * Make sure that the connector and anchor are oriented correctly. Attachment



4. Temporarily mount the O-ring to the top of the connector at the mating surface.



5. Mate the Connector Waterproof Cover (XS2Z-22, sold separately) or the Partner Connector Plug (XS5H-T42□-□M0-K, sold separately) and press the O-ring to the O-ring position after mounting.



Connector Waterproof Cover (Sold Separately) XS2Z-22



* Tightening torque: 0.39 to 0.49 N·m

Safety Precautions

Precautions for Correct Use

Do not use the Connectors in an atmosphere or environment that exceeds the specifications.

Connector Connection and Disconnection

- When connecting or disconnecting Connectors, be sure to hold the Connectors.
- Do not hold the cable when disconnecting Connectors.
- When joining Connectors, be sure to insert the plug all the way to the back of the socket before attempting to lock the Connectors.
- Do not use tools of any sort to join the Connectors. Always use your hands. Pliers or other tools may damage the Connectors.

Wiring

Lay the cables so that external force is not applied to the Connectors. Otherwise, the degree of protection (IP67) may not be achieved.

Degree of Protection for M12/SmartClick Connectors

- The degree of protection of Connectors (IP67) is not for a fully watertight structure. Do not use the Connectors underwater.
- Do not step on or place any objects on the Connectors. Doing so may damage the Connectors.

Handling Precautions

- Do not pull on the Connectors or cables with excessive force. Do not install the Connectors with a load placed directly on the joint or at the point where the wires connect to the Connector. The Connector may be damaged or the wires in the cable may be disconnected.
- Lay the cable where it will not be stepped on to prevent the wires in the cable from being disconnected and to protect the Connectors from being damaged. If the cable must be placed where it will be stepped on, install a protective cover.
- When bending cables, do not exceed the cable specifications.

- Application examples provided in this document are for reference only. In actual applications, confirm equipment functions and safety before using the product.
- Consult your OMRON representative before using the product under conditions which are not described in the manual or applying the product to nuclear control systems, railroad systems, aviation systems, vehicles, combustion systems, medical equipment, amusement machines, safety equipment, and other systems or equipment that may have a serious influence on lives and property if used improperly. Make sure that the ratings and performance characteristics of the product provide a margin of safety for the system or equipment, and be sure to provide the system or equipment with double safety mechanisms.

OMRON Corporation **Industrial Automation Company**

Tokyo, JAPAN

Contact: www.ia.omron.com

Regional Headquarters OMRON EUROPE B.V.

Wegalaan 67-69-2132 JD Hoofddorp

The Netherlands

Tel: (31)2356-81-300/Fax: (31)2356-81-388

OMRON ASIA PACIFIC PTE. LTD.

No. 438A Alexandra Road # 05-05/08 (Lobby 2), Alexandra Technopark, Singapore 119967

Tel: (65) 6835-3011/Fax: (65) 6835-2711

OMRON ELECTRONIC COMPONENTS LLC 55 Commerce Drive, Suite B

Shaumburg, IL, 60173, U.S.A Tel: (1) 847-882-2288/Fax: (1) 847-882-2192

OMRON (CHINA) CO., LTD. Room 2211, Bank of China Tower,

200 Yin Cheng Zhong Road, PuDong New Area, Shanghai, 200120, China Tel: (86) 21-5037-2222/Fax: (86) 21-5037-2200 Authorized Distributor:

© OMRON Corporation 2010 All Rights Reserved. In the interest of product improvement, specifications are subject to change without notice.

CSM 4 1

Cat. No. G019-E1-02

0412(0710)(O)